


AR Series

產品爆炸圖暨零件表 AR10,16,22



AR Axial piston pump exploded view

AR10,16,22 PUMP

Item		Item	
1	Pump body	31	Sleeve piston
2	Swashplate	32	O-ring
3	Shaft	34	Ball guide
4	Trunnion carrier	35	Pin-cylinder block
5	Body seal	36	Slipper retainer
6	Servo piston sleeve	37A	Piston shose
7	Servo carrier	37	Piston assembly
8	Servo spring	38	Cylinder block
9	Pump cover	39	Valve plate
10	Flow sleeve	40	Snap ring
11	Flow pin	41	Washer cylinder block
12	Seal pin	42	Spring-cylinder block
17	Shaft bearing	43	Circular sticker
18	Snap ring	44	Square sticker
19	Cover bearing	45	Nameplate
20	Shaft seal	46	Motor pin
21	Cover screw	47	Screw
22	Snap ring	48	Washer
23	Screw	61	Flange
24	Plug	62	O-ring
25	Key	63	Plug
26	Roller	64	Plug
27	Pin-trunnion carrier	65	Adaptor
29	Nut	66	Spindle
		67	Screw
		68	O-ring